



**Specifications** 

Copyright © 2015 Dell Inc. All rights reserved. This product is protected by U.S. and international copyright and intellectual property laws. Dell and the Dell logo are trademarks of Dell Inc. in the United States and/or other jurisdictions. All other marks and names mentioned herein may be trademarks of their respective companies.

2015-07 Rev. A00

Regulatory model: P20T | Type: P20T004 Computer model: Inspiron 11-3158



# **Front**

Left

Front



Right



Base



Display



Modes

### Power/Battery status light

Indicates the power state and battery state of the computer.

Solid white — Power adapter is connected to the computer and the battery is being charged.

Solid yellow — Battery charge is low or critical.

 ${\sf Off}-{\sf Power}$  adapter is connected to the computer and battery is fully charged or power adapter is not connected to the computer.



## Left

Front

Left



Right




Base



Display



Modes



#### Power-adapter port

Connect a power adapter to provide power to your computer and charge the battery.

#### HDMI port

Connect a TV or another HDMI-in enabled device. Provides video and audio output.

#### USB 3.0 port with PowerShare

Connect peripherals such as storage devices, printers, and so on. Provides data transfer speeds up to 5 Gbps.

PowerShare allows you to charge your USB devices even when your computer is turned off.

**NOTE:** If your computer is turned off or in Hibernate state, you must connect the power adapter to charge your devices using the PowerShare port. You must enable this feature in the BIOS setup program.

**NOTE:** Certain USB devices may not charge when the computer is turned off or in the Sleep state. In such cases, turn on the computer to charge the device.

#### USB 3.0 port

Connect peripherals such as storage devices, printers, and so on. Provides data transfer speeds up to 5 Gbps.

#### **Headset port**

Connect a headphone, a microphone, or a headphone and microphone combo (headset).

#### 6 Left speaker

Provides audio output from your computer.



Front

Left



Right



Base



Display



Modes

## Right



#### **Power button**

Press to turn on the computer if it is turned off or in Sleep state.

Press to put the computer in Sleep state if it is turned on. Press and hold for 4 seconds to force shut-down the computer.

NOTE: You can customize the power-button behavior in Power Options. For more information, see Me and My Dell at www.dell.com/support/ manuals.

#### Volume-control buttons (2)

Press to increase or decrease the volume.

#### Right speaker

Provides audio output from your computer.

### USB 2.0 port

Connect peripherals such as storage devices, printers, and so on. Provides data transfer speeds up to 480 Mbps.

#### Media-card reader

Reads from and writes to media cards.

#### Security-cable slot

Connect a Noble security-cable to prevent unauthorized movement of your computer.



--- Base

Front

· - - -

Left



Right



Base



Display



Modes



#### Left-click area

Press to left click.

### 2 Touch pad

Move your finger on the touch pad to move the mouse pointer. Tap to left click.

### 3 Right-click area

Press to right click.



Front

Left



Right



Base




Display



Modes





### Left microphone

Provides high-quality digital sound input for audio recording, voice calls, and so on.

### **Ambient-light sensor**

Detects the ambient light and automatically adjusts the display brightness.

#### Camera

Allows you to video chat, capture photos, and record videos.

#### Camera-status light

Turns on when the camera is in use.

#### 5 **Right microphone**

Provides high-quality digital sound input for audio recording, voice calls, and so on.

#### 6 Windows button

Press to go to the Start screen.






Modes

Front

Notebook





Left



Right



Base



Display



Modes



Stand



**Tablet** 



Tent





## **Dimensions and weight**

Height	19 mm (0.75 in)
Width	300 mm (11.81 in)
Depth	201 mm (7.91 in)
Weight	1.39 kg (3.06 lb)
	<b>NOTE</b> : The weight of your laptop varies depending on the configuration ordered and the manufacturing variability.









connectors



















Media-card reader







Touch pad

Power adapter



## **System information**

Computer model	Inpiron 11-3158
Processor	6 <sup>th</sup> Generation Intel Core i3 Processor
	6 <sup>th</sup> Generation Intel Core i5 Processor
Chipset	Integrated in processor























reader

















### Memory

Slot One SODIMM slot

Type DDR3L

Speed 1600 MHz

Configurations supported: 4 GB







information



Memory



Ports and connectors



Communications



Video



Audio



Storage



Media-card reader



Display



Keyboard

















### Ports and connectors

External:		
Externat.		
USB	One USB 2.0 port	
	One USB 3.0 port	
	<ul> <li>One USB 3.0 port with PowerShare</li> </ul>	
Audio/video	One HDMI port	
	<ul> <li>One headphone and microphone combo (headset) port</li> </ul>	
Internal:		

One M.2 slot for Wi-Fi and Bluetooth combo card



M.2





































### Communications

Wireless

- Wi-Fi 802.11b/g/n
- Wi-Fi 802.11ac
- Bluetooth 4.0
- Intel WiDi (optional)





















reader

















### Video

Controller Intel HD Graphics

Memory Shared system memory

















ıs Video





















### **Audio**

Controller Conexant CX6008 with Waves MaxxAudio

**Speakers** Two

Speaker output:

Average 2 W Peak 2.5 W

Microphone Digital-array microphones in camera assembly

Volume controls Media-control shortcut keys and volume-control buttons



Dimensions and weight



information



Memory



Ports and connectors



Communications



Video



Audio



Storage



Media-card reader



Display Keyboard













Power adapter





### **Storage**

Interface Hard drive SATA 6 Gbps

- One 2.5-inch drive
- One 2.5-inch hybrid state
- One 2.5-inch solid-state drive























Media-card reader



















### Media-card reader

One SD card slot Type

















Memory



Touch pad

















### Display

11.6-inch HD WI FD touch Type

Resolution (maximum) 1366 x 768

Dimensions:

168.50 mm (6.63 in) Height Width 268.50 mm (10.57 in) Diagonal 294.64 mm (11.60 in)

Refresh rate 60 Hz

Operating angle 0 degrees (closed) to 360 degrees

Pixel pitch 0.1875 mm

Controls Brightness can be controlled using shortcut keys.







information



Memory



Ports and connectors



Communications



Video



Audio



Storage



Media-card reader



Display




















### **Keyboard**

Type Chiclet keyboard Shortcut keys Some keys on your keyboard have two symbols on them. These keys can be used to type alternate characters or to perform secondary functions. To type the alternate character, press Shift and the desired key. To perform secondary functions, press Fn and the desired key.

> **NOTE**: You can change the behavior of the shortcut keys by pressing Fn+Esc or by changing **Function Key Behavior** in System Setup.

List of shortcut keys.



































Power adapter



## **Shortcut keys**



Decrease volume

■") Increase volume

►/ II Play/Pause

P Open Search charm

Open Share charm

Open Devices charm


Open Settings charm

List recently-used apps

Display active app menu-bar

Decrease brightness

Increase brightness





### Camera

Resolution:

Still image 0.72 megapixel

1280 x 720 (HD) at 30 fps (maximum) Video

Diagonal viewing angle 74 degrees















Video



Audio



Storage



reader

















### Touch pad

Resolution:

Horizontal 1207 dpi Vertical 1702 dpi

Dimensions:

Width 105.20 mm (4.14 in)

Height 60.20 mm (2.37 in)













Ports and connectors







Video



Audio



Storage



Media-card reader



Display

















### **Battery**

3 cell Type

Dimensions:

Width 254 mm (10 in)

77.20 mm (3.04 in) Depth

6.80 mm (0.27 in) Height

Weight (maximum) 0.25 kg (0.55 lb)

11.4 VDC Voltage

Charging time when the

computer is off (approximate)

Operating time Varies depending on operating conditions and can significantly reduce under

Within 4 hours

certain power-intensive conditions.

Life span (approximate) 300 discharge/charge cycles

Temperature range:

0°C to 35°C (32°F to 95°F) Operating

Storage -40°C to 65°C (-40°F to 149°F)

Coin-cell battery CR-2032



Dimensions and weight



information



Memory



Ports and connectors



Communications



Video



Audio



Storage



Media-card reader



Display



Keyboard



Camera



Touch pad



Power adapter



environment



### **Power adapter**

Type 45 W

Input voltage 100 VAC-240 VAC

Input frequency 50 Hz-60 Hz

Input current 1.30 A

Output current 2.31 A

Rated output voltage 19.50 VDC

Temperature range:

Operating 0°C to 40°C (32°F to 104°F)

Storage -40°C to 70°C (-40°F to 158°F)



Dimensions and weight



System information



Memory



Ports and connectors



Communications



Video



Audio



Storage



Media-card reader



Display



Keyboard



Camera Tou



Touch pad





Power adapter



environment



### **Computer environment**

Airborne contaminant level	G1 as defined by ISA-S71.04-1985	
	Operating	Storage
Temperature range	0°C to 35°C (32°F to 95°F)	-40°C to 65°C (-40°F to 149°F)
Relative humidity (maximum)	10% to 90% (non-condensing)	0% to 95% (non-condensing)
Vibration (maximum)*	0.66 GRMS	1.30 GRMS
Shock (maximum)	110 G <sup>†</sup>	160 G <sup>‡</sup>
Altitude (maximum)	–15.2 m to 3048 m (–50 ft to 10,000 ft)	-15.2 m to 10,668 m (-50 ft to 35,000 ft)

<sup>\*</sup> Measured using a random vibration spectrum that simulates user environment.



















Audio





reader















<sup>†</sup> Measured using a 2 ms half-sine pulse when the hard drive is in use.

<sup>‡</sup> Measured using a 2 ms half-sine pulse when the hard-drive head is in parked position.